

6



0

# two-wire 2 to 8 zone fire alarm control panel and ancillaries



You're safe with C-TEC

## Two-wire AlarmSense 2-8 Zone Fire Alarm Control Panel & Ancillaries



The AlarmSense® CFP two-wire fire panel is designed to work with Apollo's AlarmSense® range of detectors, call points, sounders and beacons.

Most conventional fire systems are designed to work with two pairs of wires per zone: one pair for detection devices such as smoke detectors, heat detectors and manual call points; the other for alarm devices such as bells, sounders or strobes. By using different voltage bands for quiescent and alarm states, AlarmSense® components can be connected to the same pair of supply wires.

When powered and controlled by the CFP two-wire fire panel, this reliable technology takes all the complexity out of fire alarm system design, leading to quicker, less expensive and more flexible installation. Research shows an AlarmSense® two-wire system can achieve a 20-25% reduction of labour over a standard four wire conventional system.

AlarmSense® devices are acceptable for BS 5839-1 and BS 5839-6 systems making them particularly useful for fire protection in Houses of Multiple Occupation (HMOs).

### CFP ALARMSENSE FIRE PANELS & ANCILLARIES


CFP702-2	CFP AlarmSense 2 zone two-wire panel, keypad/keyswitch entry, does not extend	
CFP704-2	CFP AlarmSense 4 zone two-wire panel, keypad/keyswitch entry, does not extend	
CFP708-2	CFP AlarmSense 8 zone two-wire panel, keypad/keyswitch entry, does not extend	
CFP760	CFP 8 zone repeater panel, up to 8 per system, keypad/keyswitch entry	
CFP761	CFP network driver card (one required per repeater system, fit at main)	
CFP762	CFP relay output card (reset, fault, aux fire & remote relays)	
CFP763	CFP relay output card (reset, fault, aux fire & remote relays plus 8 output per zone relays)	
CFP764	CFP relay output card (8 output per zone relays)	
CFP765	CFP relay output card (provides 4 output per zone relays)	
CFP766	CFP relay output card (provides 2 output per zone relays)	
See page 3 for a full list of AlarmSense detectors, bases, sounders, beacons, etc		



# **CFP AlarmSense features**

- Designed to comply with EN54 Parts 2 and 4
- Available with 2, 4 or 8 AlarmSense zone circuits (dependent on model purchased)
- Intuitive user-friendly interface with colour-coded buttons and combined keypad/keyswitch entry to access level 2
- Four conventional sounder circuits (for use with non-AlarmSense sounders)
- Integral 1.5A EN54-4/A2 compliant switch mode PSU
- Wide range of engineering functions including zone test, coincidence, zone delay and non-latching zones
- Two on-board relays (Fire and Fault)
- Two open-collector outputs (Remote and Reset)
- 'Class change' and alert inputs
- Installer-friendly design accommodates easy first fix and straightforward maintenance
- Attractive flush or surface mountable plastic lid and enclosure - no bezel required

- Low quiescent current
- Multiple indicators
- End of line units included (one per zone)
- Ancillary system expansion connections provided for up to eight two-wire repeaters (one CFP761 network driver card required per system) and optional CFP relay boards
- Space for two x 12V 3.2Ah VRLA batteries
- Third-party LPCB tested



### ALARMSENSE DETECTORS

### BF302ASH (55000-190) STANDARD HEAT DETECTOR



A rate of rise (A1R) heat detector. Housed in a pure white polycarbonate moulding and fitted with two LEDs in order to allow 360° visibility. Requires AlarmSense base.

### BF316ASH (55000-390) OPTICAL DETECTOR



An optical detector working on the light scatter principle. Changes alarm state at a pre-set threshold of smoke penetration in its sensing chamber. Requires AlarmSense base.

### BF302ASHH (55000-193) HIGH TEMP. HEAT DETECTOR



A fixed temperature (CS) heat detector. Housed in a pure white polycarbonate moulding and fitted with two LEDs in order to allow 360° visibility. Requires AlarmSense base.

### BF316ASHI (55000-391) INTEGRATING OPTICAL DETECTOR



An integrating optical detector designed for use in areas where smoke is normally present. For example, a room in a house of multiple occupation which is occupied by a heavy smoker. Requires AlarmSense base.

A polarity insensitive base sounder

that is capable of indicating local and

general alarms. Includes high 87db(A) and normal 70db(A) volume settings.

Note that a BF330ASLIDR red cap or

BF330ASLIDW white cap is required

for stand alone use.

### ALARMSENSE BASES, SOUNDERS, BEACONS AND ANCILLARIES

### BF308AS (45681-244) ALARMSENSE BASE



Designed to accept any AlarmSense detector. Includes circuitry to monitor the presence of a detector and allow a fault to be signalled if a detector is removed without authorisation.

### BF330ASBSB (45681-509) BASE SOUNDER/BEACON



A polarity insensitive base sounder/beacon that is capable of indicating local and general alarms. Incudes high 87db(A) and normal 70db(A) volume settings. Note that a BF330ASLIDR red cap or BF330ASLIDW white cap is required for stand alone use.

### BF310ASR (55000-835) ALARM RELAY (RESET ON SILENCE)



Operates in three configurations:-Relay activation places zone voltage on output contact terminals

- Relay activation reverses the polarity of the zone voltage on the output terminals
- Two sets of volt-free contacts for use by door closure units, etc

BF370ASS (55000-894) MANUAL CALL POINT

BF330ASBS (45681-510) BASE SOUNDER



A special surface mounting red manual call point that can be detected as an operated call point rather than a detector that has changed to the alarm state. Includes a red LED indicator.

### BF318AS (53832-070) REMOTE INDICATOR



A light-weight remote indicator specifically designed for use with AlarmSense detectors. Measuring just 20mm high and 80mm diameter, two pairs of keyholes are provided one for 50mm and one for 60mm fixing centres.

### ALARMSENSE COMBINATIONS

### BF316ASHC (55000-392)



Optical smoke detector and sounder base combination

Also available: BF316ASHC1 (55000-394) Optical smoke detector and sounder/beacon base combination

### BF316ASHIC (55000-393)



Integrating optical smoke detector and sounder base combination

Also available: BF316ASHIC1 (55000-395) Integrating optical smoke detector & sounder/ beacon base combination

### BF302ASHC (55000-196)



Standard heat detector and sounder base combination

Also available: BF302ASHC1 (55000-198) Standard heat detector and sounder/beacon base combination

### BF302ASHHC (55000-197)



High temperature heat detector and sounder base combination

Also available: BF302ASHHC1 (55000-199) High temperature heat detector and sounder/beacon base combination

# **CFP AlarmSense Technical Specifications**

230V ±10% 50/60Hz
350mA maximum
19V - 28.5V (27V nominal), Ripple 7V maximum (battery fault)
1.5A @ 230Vac (ImaxA = 146mA)
Ri max = 1.5Ω
YES (battery charger is also temperature compensated)
YES
2 x 12V 3.2Ah VRLA type, connected in series. Minimum battery size 1.2Ah
240V 1A HRC ceramic 20mm compliant with IEC (EN60127 PT2)
1.6A F 20mm compliant with IEC (EN60127 PT2)
1.5A maximum

### Zone Circuit Specification (for use with AlarmSense devices only)

j,				
Number of circuits Max cable length per circuit Line monitored for head out, open & short circuit faults Maximum allowable impedance (each conductor) Maximum cable capacitance (per circuit) Max. number of detectors/manual call points per zone Max. number of sounders per zone	2 (CFP702-2); 4 (CFP704-2); 8 (CFP708-2)         500 metres         YES - DC monitoring         20Ω         0.27µF         25 per zone    The panel's power supply is designed to give a max. output current of 1.5A. In addition to powering the sounders, this current is also used for handling short circuit faults and supplying the panel's battery charging circuit and any output relays which may be fitted. As a safe margin and to allow for these other loads, the total sounder loading for the panel should not exceed a maximum of 1.25A. Each zone circuit and each sounder circuit sull support a max. sounder alarm current of 200mA. Currents in excess of this will cause the circuit's fuse to trip. The sounders should be distributed throughout the site according to the sound levels required, but the load should be distributed as equally as possible across each circuit.			
AlarmSense Optical & Heat Detector Specification	Quiescent current <50µA; triggered voltage 9V nominal			
AlarmSense Manual Call Point Specification	Quiescent current <50µA; triggered voltage 5V nominal			
AlarmSense Sounder Specification	Refer to individual device specifications			

Conventional Sounder Circuit Specification (for use with non-AlarmSense sounders)				
Number of circuits	4			
End of line resistor value	6800 ohm 5% Tol. 0.25W (blue, grey, red, gold)			
Each circuit monitored for open and short circuit	YES - reverse voltage DC monitoring. Indicated by common fault.			
Alarm voltage	27V maximum, 20V minimum (final battery voltage)			
Sounder circuit fuses	Each circuit protected by resetable fuses. (200mA min. hold current; 400mA max. trip current;			
	Approx. 50mA when tripped. Reset when faults removed)			
Maximum total sounder output current to all outputs	4 x 200mA = 800mA			
Maximum No. of bells @ 25mA	32			
Maximum No. of electronic sounders @ 20mA	40 (sounders must be polarised)			
Auxiliary Relay Outputs				
Aux. Fire relay output (AUX)	Voltage free single pole changeover; Max. switching current 1A; Max. switching voltage 30Vdc			
Fault relay output (FAULT)	Voltage free single pole changeover; Max. switching current 1A; Max. switching voltage 30Vdc			

radic relay output (rAoEr)	Voltage free single pole changeover, Max. switching current 14, Max. switching voltage sovice
Auxiliary Open Collector Outputs	
Reset auxiliary output (RESET) Remote auxiliary output (REM)	Non monitored, open collector type. Active during reset cycle. Non monitored, open collector type. Active during any fire condition (provided all relevant delays have expired)
Max. sink current Max. open circuit voltage 24V aux power output (for use with the above)	30mA each 27Vd.c Output protected by a resetable fuse (100mA min. hold current). Fuse resets when fault removed
Auxiliary Inputs	
Class Change (makes sounders sound continuously) Alert (makes sounders pulse intermittently)	Connect to OV to trigger. Max. input voltage 27V. (Non-latching) Connect to OV to trigger. Max. input voltage 27V. (Non-latching)
Dimensions	

Dimensions	
Physical size	Size = 380 x 235 x 96mm approx.
Weight	1.75kg (without batteries)

### Priority and Non-priority sounder setting

AlarmSense sounder and sounder beacon bases may be set to provide either a general (priority) or a local (non-priority) alarm. In houses of multiple occupation they are typically set to 'non-priority' in individual flats or apartments to give a local alarm and 'priority' in communal areas, circulation spaces and escape routes to give a general alarm. In the event of a detector in an apartment going into alarm, the CFP AlarmSense panel will switch the associated sounder or sounder beacon to non-priority alarm. This will give the flat's occupant 2 minutes to investigate and remove any cause of false alarm. If the cause of the alarm is cleared within 2 minutes the system will reset. If the detector is still activated after 2 minutes, or another detector elsewhere on the system goes into alarm, the CFP AlarmSense panel will switch all of the system's sounders to full alarm.



### Manufactured by C-TEC, Stephens Way, Wigan, WN3 6PH. England

UK Sales: Tel: 01942 322744. Fax: 01942 829867. Email: sales@c-tec.co.uk European Sales: Tel: +44 1942 322744. Fax: +44 1942 829867. Email: eu.exports@c-tec.co.uk Export Sales: Tel: +44 161 257 2541. Fax: +44 161 225 8817. Email: xportsales@xportsales.com



© C-TEC. Errors and omissions excepted. C-TEC operates a policy of continuous improvement and we reserve the right to alter product specifications at our discretion and without prior notice. Approved Document No. DML0501000 Rev 1

